

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								Refer to Page
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
* DRIVE BELT		NOTE (4)				I	R			—	
* BELT CASE AIR CLEANER					C		C		C	—	
* FINAL DRIVE OIL		NOTE (6)								—	
BRAKE FLUID		NOTE (5)		I	I	R	I	I	R	31–32	
BRAKE PADS WEAR				I	I	I	I	I	I	112, 113	
BRAKE SYSTEM			I		I		I		I	28–32, 112, 113	
* BRAKE LIGHT SWITCH					I		I		I	—	
* BRAKE LOCK OPERATION			I	I	I	I	I	I	I	114	
* HEADLIGHT AIM					I		I		I	64	
** CLUTCH SHOES WEAR				I	I	I	I	I	I	—	
SIDE STAND					I		I		I	111	
* SUSPENSION					I		I		I	110	
* NUTS, BOLTS, FASTENERS			I		I		I		I	—	
** WHEELS/TYRES					I		I		I	—	
** STEERING HEAD BEARINGS			I		I		I		I	—	