

5. Tyres—check condition and pressure (pages 40 – 45 ).
6. Throttle—check for smooth opening and full closing in all steering positions (page 107).
7. Lights and horn—check that headlight, brake/tail lights, position lights, license light, turn signals, indicators and horn function properly.
8. Engine stop switch—check for proper function (page 52 ).
9. Side stand ignition cut-off system—check for proper function (page 111 ).