


## Instruments and Indicator Lights

The instruments are grouped together above the headlight case. The indicator lights are located between the instruments.

- |                                 |  |
|---------------------------------|--|
| (1) Tripmeter                   | (10) Tripmeter reset knob                          |
| (2) Speedometer                 | (11) Oil pressure warning light                    |
| (3) Odometer                    | (12) High beam indicator                           |
| (4) Left turn signal indicator  | (13) Neutral indicator                             |
| (5) Coolant temperature gauge   | (14) Rear suspension<br>air pressure warning light |
| (6) Fuel gauge                  |  |
| (7) Right turn signal indicator |  |
| (8) Tachometer                  |  |
| (9) Tachometer red zone         |  |



## Instrumentos y Lámparas Indicadoras

Los instrumentos se encuentran agrupados encima de la caja del faro. Las lámparas indicadoras están situadas dentro de los instrumentos.

- |   |   |   |
|---|---|---|
| (1) Cuenta-kilómetro                                      | (7) Luz indicadora de señales<br>de vuelta a la derecha | (12) Luz indicadora del haz alto<br>del faro                      |
| (2) Indicador de velocidad                                | (8) Tacómetro   | (13) Luz indicadora de neutro                                     |
| (3) Odómetro  | (9) Zona roja del tacómetro                             | (14) Luz indicadora de presión de<br>aire para suspensión trasera |
| (4) Luz indicadora de señales<br>de vuelta a la izquierda | (10) Botón de reposición del<br>cuenta-kilómetro        |   |
| (5) Indicador de temperatura<br>del refrigerante          | (11) Luz de aviso de la presión<br>de aceite            |   |
| (6) Indicador de nivel de gasolina                        |   |   |