## ACC TERMINAL

The ACC terminal is in the fuse box (page 132) and provides 12 V DC power for electrical accessories. A maximum of 60 watts (5 amps) may be connected to the terminal. If equipped with accessories, check the battery frequently to determine the state of charge and examine it for possible sulfation. Higher current demands may blow the fuse or discharge the battery. Review the LOADING AND ACCESSORIES WARNING (page 6) before installing accessories. Connect accessory electrical leads securely, and keep them insulated, away from hot parts and sharp edges.

## CAUTION:

Do not exeed 5 amps for prolonged current demands.

