

# OPERATION

---

## Starting Procedure (except SI)

To restart a warm engine, follow the procedure for “High Air Temperature.”

Normal Air Temperature 10° – 35°C (50°–95°F):

1. Push the choke lever down all the way to fully ON (A), if the engine is cold.
2. Start the engine, leaving the throttle closed.

### NOTE:

- Do not open the throttle when starting the engine with the choke ON. This will lean the mixture, resulting in hard starting.
3. Immediately after the engine starts, operate the choke lever to keep fast idle at 1,500 – 2,500 min<sup>-1</sup> (rpm).
  4. About a half minute after the engine starts, pull the choke lever up all the way to fully OFF (B).
  5. If idling is unstable, open the throttle slightly.

