

CONTENTS

MAINTENANCE

Page

128 MAINTENANCE

- 128 THE IMPORTANCE OF MAINTENANCE
- 129 MAINTENANCE SAFETY
- 130 SAFETY PRECAUTIONS
- 131 MAINTENANCE SCHEDULE
- 133 TOOL KIT
- 134 SERIAL NUMBERS
- 135 COLOUR LABEL
- 136 COVER REMOVAL
- 141 ENGINE OIL
- 146 CRANKCASE BREATHER
- 147 SPARK PLUGS
- 149 FINAL DRIVE OIL
- 150 COOLANT
- 151 FRONT AND REAR SUSPENSION INSPECTION
- 152 SIDE STAND
- 153 WHEEL REMOVAL
- 160 BRAKE PAD WEAR
- 161 BRAKE SYSTEM INSPECTION
- 162 BATTERY
- 164 FUSE REPLACEMENT
- 166 BULB REPLACEMENT
- 173 CLIP REMOVAL AND INSTALLATION

174 CLEANING

178 STORAGE GUIDE

- 178 STORAGE
- 179 REMOVAL FROM STORAGE

180 SPECIFICATIONS

182 CATALYTIC CONVERTER

183 NOISE CONTROL SYSTEM (AUSTRALIA ONLY)