


---

## VENTILATION


### Side Ventilation Louvers

This motorcycle has upper and lower side ventilation louvers. Open the upper and lower louvers to direct fresh air.


LEFT UPPER



LEFT LOWER



### Windshield Ventilation Louvers



You can adjust the windshield ventilation with the lever to control and direct the flow of fresh air.