



ESSENTIAL INDIVIDUAL COMPONENTS

Whenever the ignition switch is turned ON, the light operation is canceled.

When approximately 5 seconds past without operating a button, the display automatically returns to the previous display.

If the system repeatedly does not recognize the coding of your key, contact your dealer.

- The system may not recognize the key's coding if any other immobilizer key is near the ignition switch. To make sure the system recognizes the key code, keep each immobilizer key on a separate ring.
- Do not attempt to alter the immobilizer system (HISS) or add other devices to it. Electrical problems could result, making it impossible to start your motorcycle.
- If all keys are lost, the PGM-FI unit/ignition control module must be replaced.

