



ITEM	FREQUENCY	PRE-RIDE CHECK (P.118)	ODOMETER READING (※1)						ANNUAL CHECK	REGULAR REPLACE	Refer to page
			× 1000 km	1	12	24	36	48			
			× 1000 mi	0.6	8	16	24	32			
* FUEL LINE				I	I	I	I	I		—	
FUEL LEVEL		I								44	
* THROTTLE OPERATION		I		I	I	I	I	I		—	
* AIR CLEANER ※2					R		R			—	
CRANKCASE BREATHER ※3				C	C	C	C	C		148	
SPARK PLUG					R		R			149	
* VALVE CLEARANCE					I		I			—	
ENGINE OIL		I		R	R	R	R	R		143	
ENGINE OIL FILTER				R	R	R	R	R		145	
* ENGINE IDLE SPEED				I	I	I	I	I		—	
RADIATOR COOLANT ※4		I		I	I	I	I	I	3 years	42, 151	
* COOLING SYSTEM				I	I	I	I	I		—	
* SECONDARY AIR SUPPLY SYSTEM				I	I	I	I	I		—	
* FINAL DRIVE OIL									3 years	—	
BRAKE FLUID ※4		I		I	I	I	I	I	2 years	37, 39	
BRAKE PADS WEAR		I		I	I	I	I	I		162	
BRAKE SYSTEM				I	I	I	I	I		37, 39, 162	
* BRAKELIGHT SWITCH				I	I	I	I	I		—	
* HEADLIGHT AIM				I	I	I	I	I		65	
LIGHTS/HORN		I								59	
ENGINE STOP SWITCH		I								58	
CLUTCH SYSTEM				I	I	I	I	I		40	
CLUTCH FLUID ※4		I		I	I	I	I	I	2 years	40	
SIDE STAND		I		I	I	I	I	I		153	
* SUSPENSION				I	I	I	I	I		152	
* NUTS, BOLTS, FASTENERS				I	I	I	I	I		—	
** WHEELS/TYRES		I		I	I	I	I	I		—	
** STEERING HEAD BEARINGS				I	I	I	I	I		—	

