



MAINTENANCE

COLOUR LABEL

The colour label is attached inside the fuel filler lid (page 44).
It is helpful when ordering replacement parts. Record the colour and code here
for your reference.

COLOUR _____

CODE _____

Colour label

