



BRAKE SYSTEM INSPECTION

Refer to the Safety Precautions on page 131.

Check the brake system as follows:

1. Place the motorcycle on its side stand, stop the engine, and place the transmission in neutral.
2. Support the motorcycle securely, raise the rear wheel off the ground.
3. Move the left caliper assembly upward while slowly rotating the rear wheel.
The brake system is normal if the rear wheel stops. If the rear wheel does not stop, see your dealer.

