



- | | | |
|--------------------------------------|------------------------------------|---------------------|
| ① Main switch | ② Fuel valve | ③ Gear change pedal |
| ④ Fuel mixture enrichment lever | ⑤ Engine oil tank cap (under seat) | |
| ⑥ Engine oil level inspection window | ⑦ Seat lock | |