

Ref. No.	Description	Function
1	Speedometer	Indicates driving speed.
2	Odometer	Indicates total accumulated distance traveled.
3	Tripmeter	Indicates distance traveled per trip. (meter can be reset for each trip)
4	High beam indicator light (blue)	Light will be on when headlight is on high beam.
5	Neutral indicator light (green)	Light will be on when the transmission is in neutral.
6	Tachometer	Indicates engine rpm.
7	Turn signal indicator light (amber)	Light will flash when either turn signal light is operating.
8	Tachometer red zone	During acceleration, engine RPM indicator needle may be allowed to briefly enter the red zone. However, the motorcycle must not be operated in the red zone for any length of time and must NEVER be operated beyond it.