



1. Loosen the lock nut ② and then turn the front brake adjusting nut ③. Turning the nut in direction ① will decrease the brake lever free play and turning the nut in direction ② will increase the play.



- ② Lock nut
- ③ Front brake adjusting nut

2. Minor adjustments can be made with the front brake cable adjuster on the front brake lever.

Remove the dust cover ④, loosen the lock nut ⑤ and turn the front brake cable adjuster ⑥. Turning the adjuster in direction ① will decrease the brake lever free play and turning the adjuster in direction ② will increase the play.



- ④ Dust cover
- ⑤ Lock nut
- ⑥ Front brake cable adjuster