

## TROUBLE SHOOTING

Use the following table to help determine the cause of problems with your Honda motorcycle. Contact your Honda dealer for assistance in matters beyond the scope of the table.

### 1. Engine will not start.

	<b>Cause</b>	<b>Remedy</b>
Fuel system	<ol style="list-style-type: none"><li>1. Insufficient gasoline.</li><li>2. Clogged fuel cock.</li><li>3. Clogged tank cap breather tube.</li><li>4. Clogged fuel tube.</li></ol>	<p>Add. Clean. Clean. Clean.</p>
Electrical system	<ol style="list-style-type: none"><li>1. Damaged, wet or fouled plug.</li><li>2. Incorrect plug gap.</li><li>3. Dirty or damaged contact points.</li><li>4. Incorrect point gap.</li><li>5. Incorrect ignition timing.</li></ol>	<p>Replace or clean. Adjust. Replace or clean. Replace or adjust. Adjust.</p>
Compression	<ol style="list-style-type: none"><li>1. Loose spark plug.</li><li>2. Loose cylinder head.</li></ol>	<p>Retighten. Retighten.</p>