

# Tool Kit

---

The tool kit is stored in the tool kit compartment under the driver's seat.

To access the tool kit, open the left door (page 23), left side net (page 25) and remove the left seat (page 83), and then remove the rubber dust cover.

An optional, larger tool kit may be available. Check with your Honda dealer's parts department.

## UNDER LEFT SEAT

