

MAINTENANCE SCHEDULE This maintenance schedule is based upon average riding conditions. Machines subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.	PRE-RIDING INSPECTION	INITIAL SAFETY INSPECTION	REGULAR SERVICE PERIOD Perform at every indicated month or mileage interval, whichever occurs first.	
		1 month 300 km	12 months 1,500 km	24 months 3,000 km
*TIRES AND PRESSURE	I			
CONTACT BREAKER POINTS		I	I	
IGNITION TIMING		I	I	
*THROTTLE OPERATION	I			
WHEEL TRUENESS AND SPOKES		I	I	
NUTS, BOLTS (TIGHTEN)		I	I	
BRAKE LININGS			I	
*BATTERY FLUID LEVEL	I			
BATTERY FLUID SPECIFIC GRAVITY			I	
SPARK PLUG	(EVERY 500 km) I			

I—Inspect, clean, adjust or replace if necessary R—Replace C—Clean L—Lubricate