BRAKE SHOE WEAR

(Refer to the maintenance precautions on page 75).


The rear brake has a wear indicator mark.

When you brake, a reference symbol (1) moves towards an arrow (2) on the brake arm (3). If the arrow lines up with the reference symbol when the brake is fully on, the brake shoe needs to be changed.

Contact your Honda dealer to carry out this operation.

NOTE:

 Only use original Honda parts or equivalent, on sale at authorized Honda dealers. When the brakes need servicing contact your Honda dealer.



- Reference symbol
- (2) Arrow
 - Brake arm