

5. Tyres—check condition and pressure (pages 42 - 47 ).
6. Throttle—check for smooth opening and full closing in all steering positions (page 129).
7. Lights and horn—check that headlight, brake/tail light, position light (except U type), license light, turn signals, indicators and horn function properly.
8. Engine stop switch—check for proper function (page 54 ).
9. Side stand ignition cut-off system—check for proper function (page 133 ).