

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			× 1,000 km	1	6	12	18	24	30	36	
			× 1,000 mi	0.6	4	8	12	16	20	24	
	FINAL DRIVE OIL				I		I		R	127	
	BRAKE FLUID	NOTE (4)		I	I	R	I	I	R	32, 34	
	BRAKE PADS WEAR			I	I	I	I	I	I	141, 142	
	BRAKE SYSTEM		I		I		I		I	32-34, 141-142	
*	BRAKELIGHT SWITCH				I		I		I	149	
*	BRAKE LOCK OPERATION		I	I	I	I	I	I	I	150	
*	HEADLIGHT AIM				I		I		I	86	
	SIDE STAND				I		I		I	133	
*	SUSPENSION				I		I		I	132	
*	NUTS, BOLTS, FASTENERS		I		I		I		I	-	
**	WHEELS/TYRES				I		I		I	-	
**	STEERING HEAD BEARINGS		I		I		I		I	-	