



Front Turn Signal Bulb

1. Remove the socket (1) turn it counterclockwise and pull out the bulb (2).
2. Install a new bulb in the reverse order of removal.



- (1) Socket
(2) Bulb