

## Average Fuel Consumption Meter


The meter shows average fuel consumption in km/ℓ or ℓ/100 km based on the tripmeter A.

To select km/ℓ or ℓ/100 km, press and hold the mode button for more than 2 seconds with tripmeter in the display.

The meter shows average fuel consumption since you last reset tripmeter A.

When you reset tripmeter A, average fuel consumption is reset at the same time.

After you reset tripmeter A, average fuel consumption meter (1) shows “—.—”.



(1) Average fuel consumption meter