


If There Is a Failure In Honda S Matic

If switching D mode and S mode cannot be done in the automatic shift mode or shifting cannot be done in the 7-speed manual or automatic mode, "F" lights or flashes on the shift information display (1) to indicate a failure in Honda S matic. See your Honda dealer as soon as possible.

- Due to the location of a fault, traveling will be restricted to an equivalent of D mode or manual 1st speed. It will not be possible to travel at the usual riding speed.



(1) Shift information display