## **OPERATION**

Pag	e	Page	
1		39	Seat Lock
1	Safe Riding Rules	40	Adjustable Backrest
3	Protective Apparel	41	Helmet Holder
4	Modifications	42	Parking Brake
5	Loading and Accessories	43	Center Compartment
7	PARTS LOCATION	44	Document Compartment
10	Instruments and Indicators	44	Trunk Light
17	MAJOR COMPONENTS (Information	45	Glove Box
	you need to operate this scooter)	46	Ticket Box
17	Suspension	47	Accessory Socket
18	Brakes	48	Headlight Aim Vertical Adjustment
24	Coolant	49	Idle stop (NSS250A)
26	Fuel	55 O	PERATION
29	Engine Oil	55	Pre-ride Inspection
30	Tubeless Tyres	56	Starting the Engine
34		59	Running-in
	COMPONENTS	60	Riding
34	Ignition Switch	67	When the Idle Stop Switch is Set in
35	Right Handlebar Controls		the Idling Stop Position (NSS250A)
36	Left Handlebar Controls	70	Parking
38	FEATURES	71	Anti-theft Tips
	(Not required for operation)		
38	Steering Lock		