


## WHEN THE IDLE STOP SWITCH IS SET IN THE IDLING STOP POSITION (NSS250A)

The engine will stop idling about 3 seconds after you have ridden the scooter at speed above 10 km/h, brought it to a complete stop, then closed the throttle completely with the engine warmed.

The standby indicator will start flashing to indicate that the idle stop system is in operation.



### NOTE:

- \* Sustained idle stop may cause the battery to run down.