

## Front Turn Signal Bulb

1. Turn the socket (1) 90° counterclockwise and remove it.
2. Pull out the bulb (2) without turning.
3. Install a new bulb in the reverse order of removal.



- (1) Socket  
(2) Bulb