

CONTENTS

OPERATION

Page

- 1 MOTORCYCLE SAFETY
 - 1 Loading and Accessories

- 3 PARTS LOCATION
 - 6 Voltmeter

- 7 ESSENTIAL INDIVIDUAL COMPONENTS
 - 7 Right Handlebar Controls
 - 9 Hazard Switch

- 10 FEATURES (Not required for operation)
 - 10 Seat
 - 11 Document Compartment

MAINTENANCE

Page

- 12 ELECTRICAL
 - 12 Fuse Replacement
 - 13 Bulb Replacement

- 16 SPECIFICATIONS