
Starting Procedure


To restart a warm engine, follow the procedure for “High Air Temperature”.

Normal Air Temperature 10° — 35°C (50° — 95°F):

1. Pull the choke lever back all the way to Fully On (B), if the engine is cold.
2. Start the engine, leaving the throttle closed.

NOTE:

- Do not open the throttle when starting the engine with the choke on. This will lean the mixture, resulting in hard starting.



Choke Lever

3. Immediately after the engine starts, operate the choke lever to keep fast idle at 2,000 — 2,500 min⁻¹ (rpm).
4. About a half minute after the engine starts, push the choke lever forward all the way to Fully Off (A).
5. If idling is unstable, open the throttle slightly.