



//////////////////////SERIAL NUMBER LOCATION//////////////////////

The frame serial number ① is stamped on the left of the steering head. The engine serial number ② is located on the lower left side of the engine. These numbers are required when registering

the motorcycle. Refer to the frame or engine serial number when ordering replacement parts to ensure that you will obtain the correct parts for your model series.



① Frame serial number



② Engine serial number