

6. After starting, warm up the engine until the engine properly responds to the throttle with the choke fully open (position ③).

Starting in Extremely Cold Weather

Prime the engine before starting by cranking several times with the kick starter pedal. The main switch should be "OFF", the choke fully closed and the throttle opened slightly. Follow the starting procedure for a cold engine.

Starting a Warm Engine

When the engine is to be re-started while still warm, proceed as for cold engine starting, however, do not use the choke.

WARNING:

Exhaust gases contain poisonous carbon monoxide. Never run the engine in a closed garage or in a confined area.

///////BREAK-IN PROCEDURE///////

During the first 600 miles (1,000 km), operate your new ST90 so the engine neither pulls laboriously nor exceeds 80% of the maximum rpm in any gear. Avoid full throttle operation, and select your gear changes to spare the engine undue stress. Careful break-in procedure during the initial mileage will measurably extend the service life of the engine.