


NOTE: Battery removal may be necessary when battery electrolyte (SPECIFIC GRAVITY) reading is below 1.20, indicating the need for battery recharging.

CAUTION: The battery vent tube must be properly routed to prevent battery acid and corrosive fumes from contacting the motorcycle. Correct battery breather tube routing is shown in the following illustration.

When installing the battery, be careful not to pinch or kink the breather tube.



⑥ Fuse holder

