

REGULAR SERVICE PERIOD

**EVERY
30
OPERATING
DAYS**

NOTE

**Change oil
every 30
operating days
or
every 3 months,
whichever
occurs first.**

- ENGINE OIL—Change.
- SPARK PLUG—Clean and adjust gap, or replace if necessary.
- *CONTACT POINTS AND IGNITION TIMING—Clean, check, and adjust or replace if necessary.
- *VALVE TAPPET CLEARANCE—Check and adjust if necessary.
- POLYURETHANE FOAM AIR FILTER ELEMENT—Clean and oil. Service more frequently if operated in dusty areas.
- SPARK ARRESTOR—Purge
- *CARBURETOR—Check and adjust if necessary.
- *CAM CHAIN TENSION—Adjust
- THROTTLE OPERATION—Inspect cable. Check and adjust free play.
- *CLUTCH—Check operation and adjust if necessary.
- DRIVE CHAIN—Check, lubricate, and adjust if necessary.
- BRAKE CONTROL LINKAGE—Check linkage and adjust if necessary.
- *WHEELS, RIMS, AND SPOKES—Check. Tighten spokes and tire wheels if necessary.
- TIRES—Inspect and check air pressure.
- FRONT AND REAR SUSPENSION—Check operation.
- REAR FORK BUSHING—Check for excessive looseness.
- SIDE STAND—Check installation, operation, deformation, damage and wear.
- ALL NUTS, BOLTS, AND OTHER FASTENERS—Check security and tighten if necessary.