

MAINTENANCE AND REPAIRS

MAINTENANCE SCHEDULE

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean R: Replace A: Adjust L: Lubricate		EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE	YEAR I			—
*	FUEL STRAINER SCREEN	YEAR C			86, 87
*	THROTTLE OPERATION		I	I	88
*	CARBURETOR CHOKE			I	93
	AIR CLEANER	(NOTE 1)		C	89–91
	AIR CLEANER CASE DRAIN TUBE	(NOTE 2)		I	92
	SPARK PLUG			I	104, 105
*	VALVE CLEARANCE		I	I	105
	ENGINE OIL		R	R	25, 96–99
*	ENGINE OIL STRAINER SCREEN	(NOTE 3)			86–87
**	ENGINE OIL CENTRIFUGAL FILTER	(NOTE 3)			—
*	CARBURETOR IDLE SPEED		I	I	93–95
	DRIVE CHAIN	NOTE 1,2	I, L	I, L	100–102
*	BRAKE FLUID	(NOTE 4)	I	I	115, 116