

Brake Pads:

Brake pad wear will depend upon the severity of usage and riding conditions. The pads will wear faster in wet or muddy conditions. *Inspect the pads visually during all regular service intervals to determine the pad wear.*

1. Brake pads—If the wear indicator (1) aligns with the edge of the reference mark (2), both pads must be replaced, see your authorized Honda dealer for this replacement.




Fig. 4-21 (1) Wear indicator

(2) Edge of reference mark

Other Checks:

1. Make sure there are no fluid leaks.
2. Check the condition of brake hoses and fittings. If the hoses are worn or cracked, have them replaced by an authorized Honda dealer.