

# Index

---

## T

throttle	
lever.....	20, 103
tires,	
air pressure .....	126
flat .....	161
replacing.....	131
repairing .....	130
specifications.....	131
thread conditions .....	129
tool kit .....	84
training, rider.....	28
transporting your ATV .....	146
trouble, unexpected .....	153
troubleshooting, starting.....	157
turning,	
on level ground.....	58
on hills or slopes.....	65

## V

valve, fuel.....	15
valve clearance .....	112