

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	FINAL DRIVE OIL		I: (EVERY YEAR) R: (EVERY 2 YEARS)	61
	BRAKE FLUID (FRONT)	I	I *R: (EVERY YEAR)	57
*	BRAKE SHOES		I: (EVERY YEAR)	55
	BRAKE SYSTEM	I	I	55
*	CLUTCH	A	A	54
*	SUSPENSION		I	—
*	*SPARK ARRESTER		C	62
*	REVERSE LOCK MECHANISM	I	I	—
	ALL NUTS, BOLTS, FASTENERS	I	I	—
	LIGHTING EQUIPMENT	I	I	—
	TIRES	I	I	24
*	STEERING HEAD BEARINGS		A: (EVERY YEAR)	—
*	STEERING SYSTEM		I: (EVERY YEAR)	—