

Maintenance Schedule

ITEMS	FREQUENCY	WHICHEVER COMES FIRST ⇒ NOTE	INITIAL MAINT.		REGULAR MAINT. INTERVAL		Refer to page
			mi	100	600	1200	
			km	150	1000	2000	
			HOURS	20	100	200	
	REAR FINAL GEAR CASE OIL				(R:EVERY 2 YEARS)		100
*	BRAKE FLUID	NOTE 3					118
*	BRAKE SHOE WEAR	NOTE 1					129
	BRAKE SYSTEM						118
*	REVERSE LOCK SYSTEM						111
	SKID PLATES, ENGINE GUARD						138
*	CLUTCH SYSTEM						110
*	SUSPENSION						--
*	SPARK ARRESTER				C	C	117
*	NUTS, BOLTS, FASTENERS						--
**	WHEELS/TIRES						--
**	STEERING SHAFT HOLDER BEARINGS						--
**	STEERING SYSTEM						--

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official *Honda Service Manual* (page 194).

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.