

# **Index**

---

## **T**

|                                |         |
|--------------------------------|---------|
| throttle,                      |         |
| cable .....                    | 116     |
| lever.....                     | 28, 116 |
| tyres,                         |         |
| air pressure .....             | 143     |
| flat .....                     | 176     |
| replacing.....                 | 148     |
| repairing .....                | 147     |
| thread conditions .....        | 146     |
| tool kit .....                 | 96      |
| trailer hitch .....            | 33      |
| trailer towing,                |         |
| operational guidelines .....   | 46      |
| weight limits .....            | 45      |
| training, rider.....           | 38      |
| transporting your ATV .....    | 162     |
| tripmeter .....                | 19      |
| trouble, unexpected .....      | 169     |
| troubleshooting, starting..... | 172     |
| turning,                       |         |
| on level ground.....           | 70      |
| on hills or slopes.....        | 77      |

## **V**

|                       |     |
|-----------------------|-----|
| valve, fuel.....      | 22  |
| valve clearance ..... | 126 |