

Climbing hills .....	65
Clutch adjustment.....	103
Consumer information .....	139
Crossing slopes.....	74
Customer service .....	141

## D

Dimmer switch .....	20
Dipstick .....	27, 96

## E

Emission control system .....	139
Engine	
Idle speed adjustment.....	94
Break-in procedures .....	ii
Flooded engine.....	58
Starting the engine.....	55
Engine oil	
Changing oil.....	96
Checking oil level and adding oil.....	96
Oil filler cap/dipstick.....	27, 96
Recommendations .....	97
Engine stop switch.....	14
Exhaust system	
Cleaning.....	35
Purging.....	126

## F

Final gear case oil .....	100
Flag pole bracket.....	29
Flooded engine .....	58
Fuel	
Fuel recommendations .....	86
Fuel fill cap.....	25, 84
Fuel tank capacity.....	84
Fuel valve.....	26
High altitude fuel mixture adjustment .....	95
Refueling.....	84
Reserve fuel supply.....	26
Fuse	
Location .....	107
Replacement.....	108