

Skidding .....	68
Spark arrester .....	136
Spark knock .....	90
Spark plug .....	110
Specifications .....	145
Speedometer [Australia model only] .....	22
Stalling on a hill .....	71
Starter button .....	17
Starting primer knob .....	17
Storage compartment .....	35
Storing procedures .....	142

## T

Throttle	
Cable .....	95
Lever .....	21, 95
Tires	
Inflation and air pressure .....	130
Repairing .....	133
Specifications .....	131
Tread condition .....	132
Tool kit .....	86
Trailer hitch .....	34
Trailer towing	
Operational guidelines .....	44
Weight limits .....	43
Transporting procedures .....	140
Turning	
On level ground .....	66
On slopes .....	79

## V

Valve clearance .....	111
-----------------------	-----

## W

Warning labels .....	8
Water	
Draining from brakes .....	128
Riding through .....	81
Weight limits .....	43
Wheel removal .....	129
Wiring diagram .....	147