

CONTENTS

	Page
TRX300 SAFETY	1
Special Safety Messages	1
Warning Information	6
PARTS LOCATION AND OPERATION	10
Parts Location	10
Parts Operation	14
Power Controls	14
Lights	24
Gearshift Controls	27
Brake Controls	29
Fuel Tank Controls	30
Engine Oil	32
Additional Features	33
RIDING YOUR TRX300	38
Before Riding	38
Rider Preparation	38
Vehicle Preparation	40
Safe Riding Rules	48
Riding	60
Starting the Engine	61
Shifting Gears	63
Riding in Reverse	64
Making Turns	66
Riding Up Hills	69
Riding Down Hills	76
Crossing Slopes	78
Making Turns on Slopes	79
Riding Over Obstacles	80
Riding Through Water	81
Parking	82
MAINTENANCE AND REPAIRS	83
Maintenance Schedule	83
Maintenance Precautions	84
Tool Kit	86
Fuel System	88
Lubrication	102
Engine	108
Electrical System	112
Brakes	117
Wheels and Tires	128
Seat Removal	133
Skid Plates	134
Spark Arrester	136
TRANSPORTING YOUR TRX300	138
STORING YOUR TRX300	140
SPECIFICATIONS	143
WIRING DIAGRAM	145
SERIAL NUMBERS	149
INDEX	150