

Spark arrester .....	132
Spark knock .....	86
Spark plug .....	104
Specifications .....	140
Stalling on a hill .....	67, 69
Starter button .....	16
Starting primer knob .....	16
Storage compartment .....	31
Storing procedures .....	137

## T

Throttle	
Cable .....	90
Lever .....	19, 90
Tires	
Inflation and air pressure .....	125
Repairing .....	128
Specifications .....	125
Tread condition .....	127
Tool kit .....	82
Trailer hitch .....	30
Trailer towing	
Operational guidelines .....	40
Weight limits .....	39
Transporting procedures .....	134
Turning	
On level ground .....	62
On slopes .....	75

## V

Valve clearance .....	105
-----------------------	-----

## W

Warning labels .....	7
Warranty service .....	144
Water	
Draining from brakes .....	123
Riding through .....	77
Weight limits .....	39
Wheel removal .....	124
Wiring diagram .....	142