

CONTENTS

	Page
MAINTENANCE AND REPAIRS	95
Emission Requirements	95
Maintenance Schedule	96
Maintenance Precautions	98
Tool Kit	99
Fuel System	100
Lubrication	112
Engine	120
Clutch	122
Electrical System	124
Brakes	131
Wheels and Tires	141
Seat Removal	146
Engine Guard and Skid Plates	147
Spark Arrester	148
Driveshaft Boots	150
TRANSPORTING YOUR FOURTRAX	152
CLEANING YOUR FOURTRAX	155
STORING YOUR FOURTRAX	157
SPECIFICATIONS	160
WIRING DIAGRAM	162
CONSUMER INFORMATION	163
WARRANTY SERVICE	165
SERIAL NUMBERS AND COLOR LABEL	166
INDEX	167
AUTHORIZED MANUALS	173