

PARTS LOCATION AND OPERATION

PARTS LOCATION

- (1) Clutch lever/Parking brake lever
- (2) Headlight switch
Engine stop switch
Headlight dimmer switch
Starter button
- (3) Neutral indicator lamp
- (4) Ignition switch
- (5) Front brake lever
- (6) Throttle lever
- (7) Fuel tank cap




Fig. 2-1

Handlebars, from rider's point of view