

Fuel Fill Cap

After refueling, be sure to tighten the fuel fill cap (Fig. 2-17) until it clicks. To refuel refer to page 82.




Fig. 2-17

(1) Fuel fill cap