


# Controls & Features

## Headlight Switch




LEFT HANDLEBAR



(1) headlight switch

(2) headlight dimmer switch



The headlight switch (1) is used to turn the headlight and assist headlight ON (☀) or OFF (•). To operate, turn the switch to ON (☀) or OFF (•).

## Headlight Dimmer Switch



The headlight dimmer switch (2) is used to change between the high and low beams of the headlight. To operate, turn the switch to HI (≡D) for high beam, LO (≡D) for low beam.

The headlight dimmer switch will not change the assist headlight beam.