

Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		mi ⇨ km	100	600	1200		
			HOURS	150	1000	2000	
		NOTE	20	100	200		
EMISSION RELATED ITEMS	* FUEL LINE				I		—
	* THROTTLE OPERATION				I		118
	* CARBURETOR CHOKE				I		120
	AIR CLEANER	NOTE 1			C	C	113
	AIR CLEANER HOUSING DRAIN TUBE	NOTE 2			I	I	117
	SPARK PLUG				I	I	124
	* VALVE CLEARANCE			I	I	I	127
	ENGINE OIL			R	R	R	102
	ENGINE OIL FILTER			R	R	R	106
	* ENGINE IDLE SPEED			I	I	I	123

- * Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 204).