



Spark Plug

Spark Plug Recommendation

standard spark plug	IFR7L11 (NGK) or VK22PRZ11 (DENSO)
for extended high speed riding	IFR8H11 (NGK) or VK24PRZ11 (DENSO)

Use only the recommended type of spark plug in the recommended heat range.

NOTICE

Using spark plug with an improper heat range can cause engine damage.

This ATV uses spark plug that have an iridium coated centre electrode. Be sure to observe the following when servicing the spark plug.

- Do not clean the spark plug. If an electrode is contaminated with accumulated objects or dirt, replace the spark plug with a new one.
- To check the spark plug gap, use only a “wire-type feeler gauge.” To prevent damaging the iridium coating of the center electrode, never use a “leaf-type feeler gauge.”
- Do not adjust the spark plug gap. If the gap is out of specification, replace the spark plug with a new one.

