

I	
Idle speed adjustment	104
Ignition switch	14
Indicator	
Neutral indicator	22
Oil high temperature indicator	22
Reverse indicator	22
Inspection, pre-ride	44
L	
Loading	
Loading guidelines and procedures	48
Weight limits	47
Lubrication	
(see Engine oil, Gear case oil and differential oil)	
M	
Maintenance	
Precautions	92
Schedule	90
Modifications	52
Multi-function display	24
N	
Neutral indicator	22
Noise emission control system	157
O	
Obstacles, riding over	86
Odometer	26
Oil (see Engine oil, Gear case oil and differential oil)	
Oil filler cap/dipstick	35, 106
Oil filter, changing	108
Oil high temperature indicator	22
Owner's manual compartment	39