

Gearshift Lever Positions

Neutral (N)

Use neutral when you start the engine, or if it is necessary to stop briefly with the engine idling.

Drive (D)

Use this position for normal riding. The following 3 modes can be selected in the Drive (D) position; D1, D2, and ESP.

You can select the desired mode with the drive mode select switch.

Automatic shift mode (D1, D2 mode):

Use this mode for every day riding. The transmission automatically adjusts to keep the engine at the best speed for riding conditions.

The gear position indicator shows "D" and the drive mode indicator shows the selected drive mode (D1 or D2).

D1 mode:

Use this mode for maximum performance.

D2 mode:

Use this mode for maximum torque (such as carrying cargo or towing a trailer).

Manual shift mode (ESP mode):

In this mode, you can shift gears much like a manual transmission, but without operating a clutch.

You can select five forward shift positions by operating the shift switches; 1, 2, 3, 4, and 5.

The gear position indicator shows the selected position and the drive mode indicator shows "ESP."